

## INSTRUCTIONS

*This product is designed for the use by chef's.*

Appliance category: Vapour-pressure butane

### ASSEMBLY:

- 1) Make sure valve is off by turning knob in direction to Minus (-) until hand tight only. DO NOT FORCE.
- 2) Turn gas cartridge clockwise into valve body until hand tight. DO NOT FORCE.

### LIGHTING AND OPERATION:

- 1) Use only high quality Butane or Propane gas cartridge.
- 2) Shake gas cartridge a few times to warm the fuel up.
- 3) Turn the adjustment knob anti-clockwise to ¼ of the way around. The gas will blow out with a hissing sound from the mouth.
- 4) Press the red ignition button and the flame will ignite instantly.
- 5) Fuel consumption Ca. 30g/h

### WARNING:

- 1) The gas cartridge contains gaseous and liquid butane or propane. If the torch is moved rapidly, tilted too far to the side or upside down, the liquid can enter the valve and cause the flame to flare or extinguish.
- 2) Make sure blow torch is cool before tightening or removing blow torch head.
- 3) Cold weather operation
  - a) In cold weather the size of the flame will be smaller. To produce a larger flame, pre-warm the cylinder to room temperature prior to use.
  - b) There is a greater possibility that the flame will extinguish when the torch is turned upside down in cold weather.

### TEMPERATURE ADJUSTMENT:

Adjust the temperature to your needs by turning the valve into Minus (-) or Plus (+) direction to decrease or increase the flame. To turn it to the maximum (+) position does not necessarily mean to get the highest efficiency or heat.

### TURNING OFF AND STORAGE:

**REMOVE CARTRIDGE FROM BLOW TORCH HEAD WHEN NOT IN USE.**

- 1) Turn valve off.
- 2) When blow torch is cool (not before 30 seconds), turn gas cartridge anti-clockwise from valve body to disconnect, then store blow torch and cartridge separately. Observe warnings on cartridge label.



## GENERAL SAFETY RULES

- 1) Read and follow operating instructions and warnings and familiarize yourself with the blow torch before lighting or using. Review instructions and warnings periodically to maintain awareness. Do not try to operate before reading instructions.
- 2) Do not point blow torch towards face, other people or flammable objects. Never attempt to use blow torch as a cigarette lighter.
- 3) Disconnect cartridge when not in use.
- 4) Never attempt to modify the blow torch construction and never use unapproved fuels.
- 5) Treat the blow torch as you would any tool or instrument. Do not drop or otherwise abuse.
- 6) Do not use a leaking, damaged or malfunctioning blow torch.
- 7) Use only in well-ventilated areas.
- 8) Always place your work in firebrick. If you are not sure it is firebrick, do not use it.
- 9) Always wear protective gloves and use proper tools to handle hot work.
- 10) Be aware that the tip of the blow torch can get extremely hot during use. Take precautions to protect yourself and others from accidental burns. Never use the blow torch on or near combustible materials. Be especially careful around motor vehicles or any products containing fuel and beware of hidden fuel pipes and tanks.
- 11) Always make certain that the blow torch is placed on a level surface when connected to the gas cartridge to reduce the risk of accidentally tipping over. Be sure blow torch is not pointed in a direction which could cause nearby objects to ignite when torch is set down.
- 12) Always have a fire extinguisher and a bucket of water near the blow torch and work area. Do not place them in the path of the flame nor in a location where you could not reach them should a fire break out.

### DANGER:

**EXTREMELY FLAMMABLE CONTENTS UNDER PRESSURE!** Keep away from heat or flame. It is illegal and dangerous to refill the gas cartridge. Obtain new gas cartridge from your dealer. Keep out of reach of children. Avoid prolonged subjection to sunlight. Do not store near heat or in a room used for habitation. Always close burner valve and wait at least 30 seconds before removing blow torch head from cartridge. Always detach cartridge from blow torch head when not in use. Do not breathe the gas, fumes, vapour or spray. If inhaled, remove affected person to fresh air. Avoid contact with skin and eyes. For skin contact, flush with large amounts of water. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. When cartridge is empty, discard in a safe place. Do not throw in fire. Do not puncture or incinerate cartridge.

## BEDIENUNGSANLEITUNG

*spezielle Ausführung für die Gastronomie*

### MONTAGE:

- 1) Vergewissern Sie sich, dass das Ventil geschlossen ist, indem Sie den Drehknopf in Richtung des Minussymbols (-) bis zum Anschlag drehen. Ventile grundsätzlich nie mit übermässiger Kraft andrehen.
- 2) Drehen Sie den Gasbehälter im Uhrzeigersinn in das Anschlußgewinde des Brenners bis er fest sitzt. Auch hier nicht mit übermässiger Kraft andrehen.

### GEBRAUCH:

- 1) Benutzen Sie nur hochwertige Butan- oder Propan-gaskartuschen.
- 2) Stellen Sie sicher, dass das Ventil geschlossen ist (Minusposition).
- 3) Schütteln Sie den Gasbehälter kurzzeitig.
- 4) Öffnen Sie das Ventil mit einer Vierteldrehung gegen den Uhrzeigersinn. Das Gas zischt hörbar.
- 5) Pressen Sie den roten Zündknopf und die Flamme zündet sofort.

### WARNHINWEISE:

- 1) Kartuschen enthalten flüssiges Gas. Wenn die Flamme zu schnell bewegt wird, zu weit zur Seite gekippt oder die Kartusche nach unten gehalten wird, kann die Flüssigkeit durch das Ventil gelangen und die Flamme stark erweitern oder auslöschen.
- 2) Stellen Sie sicher, dass das Ventil geschlossen ist, bevor sie den Brenneraufsatz anbringen.
- 3) Betrieb bei kalter Umgebung:
  - a) Bei kalter Umgebung ist die Flamme kleiner. Eine größere Flamme erreichen Sie erst, wenn der Gasbehälter Raumtemperatur erreicht.
  - b) Die Wahrscheinlichkeit, dass die Flamme bei kalter Umgebung bei einem nach unten gerichteten Brenner erlischt ist größer.

### TEMPERATURREGULIERUNG:

Justieren Sie die Temperatur gemäß Ihren Bedürfnissen mit dem Drehknopf des Ventils in Minusrichtung (weniger) oder Plusrichtung (mehr). Die Maximalstellung + entspricht dabei nicht unbedingt der höchsten Temperatur und Energieausbeute.

### ABSCHALTEN UND AUFBEWAHRUNG:

WENN SIE DEN BRENNER LÄNGERE ZEIT NICHT VERWENDEN SO TRENNEN SIE DEN BRENNER VON DER KARTUSCHE.

- 1) Schliessen Sie das Ventil durch Drehen in Minusrichtung völlig.
- 2) Wenn der Brenner abgekühlt ist - aber frühestens nach 30 Sekunden - drehen Sie den Gasbehälter gegen den Uhrzeigersinn ab und bewahren Brenner und Gaskartusche separat auf. Beachten Sie auch die Warnhinweise auf dem Gasbehälter.

## Allgemeine SICHERHEITSHINWEISE:

- 1) Richten Sie nie die Flamme auf Ihr Gesicht, auf andere Personen oder auf entzündbare Gegenstände. In keinem Fall die Flamme als Zigarettenanzünder benutzen.
- 2) Nach dem Gebrauch den Gasbehälter vom Brenner trennen.
- 3) Nehmen Sie keine baulichen Veränderungen am Brenner vor und benutzen Sie keine unzulässigen Brennstoffe.
- 4) Behandeln Sie den Gasbrenner sorgsam. Lassen Sie ihn nicht fallen und beschädigen Sie ihn nicht auf andere Art und Weise.
- 5) Einen undichten oder sonst wie beschädigten Gasbrenner nicht benutzen.
- 6) Arbeiten Sie nur in gut belüfteten Bereichen.
- 7) Achten Sie darauf, dass keine brennbaren Gegenstände in die Nähe der Flamme kommen.
- 8) Tragen Sie Schutzhandschuhe und ggf. -brille.
- 9) Beachten Sie, dass die Brennerspitze extrem heiß werden kann. Treffen Sie Vorsichtsmaßnahmen, um sich selbst und andere vor versehentlichen Bränden zu schützen.
- 10) Vergewissern Sie sich, dass der Gasbrenner auf einer sicheren Abstellfläche abgestellt wird.
- 11) Halten Sie für den Brandschutz einen Feuerlöscher griffbereit.

### ACHTUNG

#### FEUERGEFÄHRLICHER INHALT.

Nicht in der Nähe von Heizquellen aufbewahren. Es ist untersagt, Gasbehälter selbst aufzufüllen. Einen neuen Gasbehälter erhalten Sie bei ihrem Händler. Nicht in der Reichweite von Kindern aufbewahren. Vor direkten Sonnenstrahlen schützen. Nicht in bewohnten Räumen lagern. Drehknopf immer schließen und mindestens 30 Sekunden warten, bevor sie den Brenner vom Gasbehälter entfernen. nach dem Gebrauch Gaskartusche und Brenner trennen. Gase nie einatmen, bei Inhalierung geschädigte Person zur Frischenluft tragen. Kontakt mit Haut und Augen vermeiden. Bei Hautkontakt mit viel Wasser säubern, im Falle des Kontaktes mit dem Auge mit viel Wasser sofort ausspülen und Arzt aufsuchen. Leere Gasbehälter gemäß Aufdruck entsorgen. Gasbehälter nicht durchbohren oder ins Feuer werfen.

# contacto

**Product 7541/250 Chef's Blow Torch**  
Contacto Bander GmbH, Gruitener Straße 1  
40699 Erkrath, Germany, [www.contacto.de](http://www.contacto.de)